



Delivery and Collecting Accessories

Manufacturer: Aldebaran Original instructions: English

Document version: A01

Use Case: Plato by Aldebaran is a serving Cobiot designed to assist staff in restaurants (commercial environments) by delivering dishes to customers and collecting dirty dishes to clear tables.


Model: E02100

Table of contents


Description	p. 3
Safety	p. 4
Usage	p. 6
Specifications	p. 8
More information	p. 8

Description


- 1. Drink holder (available soon)
- 2. Trays




a. Round tray




b. Single rectangular tray (available soon)




c. Double rectangular tray (available soon)




d. Anti-slip mat (available soon)



3. Collecting



a. Collecting tub



b. Collecting top cover

Safety

- ▶ Plato's Emergency button must be accessible from 360° at all times
- ► Do not use the <u>Double rectangular tray</u>, <u>Collecting tub</u> or any large accessories on Plato's <u>Top shelf</u>




8

Maximum load including accessories:

<u>Top</u> and <u>Middle shelves</u>: 10 kg each
<u>Bottom shelf:</u> 20 kg

▶ Distribute extra load so that lighter loads are on the upper shelves and heavier loads are on the <u>Bottom shelf</u>



Food Contact

If an accessory below is not compliant with the Food Contact Directive, do not place unprotected food (pieces of bread, fruit with edible skin, etc.) directly on it.

兄 "	FOOD CONTACT
Single rectangular tray	NO
Double rectangular tray	NO
Anti-slip mat	YES
Round tray	YES
Collecting tub	NO
Collecting top cover	NO

Usage

You can increase the payload surface of Plato's shelves with easy to install delivery and collecting accessories.


Plato is stable and safe during navigation with loaded delivery and collecting accessories.

Clean Plato's delivery and collecting accessories with a soft dry cloth

Please use dishes to deliver food with the Rectangular trays as they are not suitable for food contact.


Installing the trays

Place trays on the dedicated shelves, no tools needed



Setting up Plato's weight sensors

When you use accessories, the weight sensors on each shelf need to be re-calibrated



- ► Go to Plato's <u>settings</u>
- ► Press the Weight sensors button
- ► Toggle the button <u>ON</u> to activate weighing
- ► Place empty accessories on the shelves and press the <u>Tare all shelves</u> button on <u>Plato's display</u> to calibrate

Specifications

	ROUND TRAY	SINGLE RECTANGULAR TRAY	DOUBLE
Installation on robot	Fits on Top shelf, on Middle shelf and on the Collecting top cover	Fits on Top shelf	Fits on Middle shelf Food accessible from left, right and rear of Plato
Overall dimensions	40.5 cm diameter	530 mm \times 432 mm \times 60 mm	530 mm \times 432 mm \times 197 mm
Weight	0.584 kg	1.4 kg	4.7 kg
Max. load			
Top and middle shelf	9.42 kg	8.6 Kg	5.3 Kg
Bussing shelf	19.42 kg	18.6 Kg	5.3 Kg
Color	Black/Gray	gray	gray
Robot clearance to avoid collision	N/A	80 cm diameter	80 cm diameter

More information

